

ANALOG PYROMETER INSTRUCTIONS

The Analog Pyrometer Kit come with:

- A.) Thermocouple with ceramic insulation block
- B.) Insulated length of thermocouple wire
- C.) Analog pyrometer

* When wiring the thermocouple/ pyrometer

RED = NEGATIVE

YELLOW = POSITIVE

- 1.) Strip the wires back to reveal the bare wire on both ends of the insulated wire (B)
- 2.) Match the colors on the wire (B) to the thermocouple (A)
- 3.) Insert wire and secure set screws on block
- 4.) **IMPORTANT: REMOVE JUMPER ON PYROMETER!! (SEE PIC)**
- 5.) Connect stripped wire (B) to pyrometer (C)

