

How to Connect Your Thermocouple Wires

Step 1:

Loosen the screws on the positive (+) and negative (-) terminals

Step 2:

Loop the ends of the yellow and red wire

*Note: You may need to strip some of the casing off of each wire if the exposed end is not long enough

Step 3:

Place the loop for each wire behind the screw and washers on the positive (+) and negative (-) terminals.

- Loop for Yellow Wire to Positive (+) terminal
- Loop for Red Wire to Negative (-) terminal

Step 4:

Your wiring for your thermocouple is now connected. Plug the mini plug into your pyrometer and you are good to go.